

# Application Note

Document Number APL-00134

Updated 12/10/01 Rev-A



## NIC 10G and 2.5G Results Save and Transfer using DOS

### Saving results (Stats) to a file on the NIC2.5G

1. Run the desired test.
2. While in the tested processor's tab, select [Print Report] on the bottom of the screen.
3. *Report Setup*  
Select Destination file [Statistics To File]. Select OK.
4. *File Browser*  
Select [File Name] then use keyboard image to enter a file name. Select [Enter].
5. *File Browser*  
Select [OK].

### Transfer results report file to a PC.

1. *At the PC*  
Bring up a DOS Prompt.
2. Type [ FTP xxx.xxx.xxx.xxx ] (xx = NIC2.5G's IP address)
3. Type [ anonymous ] [ enter ] [ enter ]
4. Type [ dir ] (to view files)
5. Type [ get ] [ filename ] (to retrieve the file)
6. Type [ quit ] (to leave FTP)